

TRUXEDO DEUCE FRONT BULKHEAD WEATHER SEAL INSTALLATION

After kit has been installed, place L-lip weather seal across bulkhead as shown below. Cut weather seal to fit between bed rails. Lip of weather seal will overlap the underbody seal.

